

# Index


## Footboards Twin Spare Parts

Page 1.      Index  
Page 2-4.    Fotsteg Twin - Footboards Twin


Note! The images are for reference only.  
Components marked with \* contact  
spare part branch.

1527288	Index Fotsteg Twin-Index Footboards Twin	Page 1 / 1
2014-05-14		
Rev. 1	Date: 2014-05-15	

## Fotsteg Twin-Footboards Twin




Note! The images are for reference only.  
Components marked with \* contact  
spare part branch.



19	Skruv	Screw	1507383	
18	Reflex rund röd	Reflector, red	1511927	
17	Låsmutter	Locking nut	1505258	
16	Gasfjäder	Gas spring	1510728	
15	Bussning	Bushing	1506378	
14	Fotstegsstöd	Footboard support	1510719	
13	Skruv	Screw	1505315	2
12	Bricka	Washer	1504901	
11	Vibrationsdämpare	Damper	1506606	
10	Segersäkring	Ring, snap	1510701	
9	Fotstegsgivare	Sensor	1506753	3
8	Låsmutter	Locking nut	1505255	
7	Bricka	Washer	1504899	
6	Skruv	Screw	1509718	
5	Bussning	Bushing	1505505	
4	Vridcentrum vänster	Rotary center	1521816	1
3	Fotstegsplatta	Footboard plate	1510669	
2	Fotstegshållare	Footboard holder	1510675	
1	Axel	Axle	1510679	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only. Components marked with \* contact spare part branch.



19	Skruv	Screw	1507383	
18	Reflex rund röd	Reflector, red	1511927	
17	Låsmutter	Locking nut	1505258	
16	Gasfjäder	Gas spring	1510728	
15	Bussning	Bushing	1506378	
14	Fotstegsstöd	Footboard support	1510719	
13	Skruv	Screw	1505315	2
12	Bricka	Washer	1504901	
11	Vibrationsdämpare	Damper	1506606	
10	Segersäkring	Ring, snap	1510701	
9	Fotstegsgivare	Sensor	1506753	3
8	Låsmutter	Locking nut	1505255	
7	Bricka	Washer	1504899	
6	Skruv	Screw	1509718	
5	Bussning	Bushing	1505505	
4	Vridcentrum höger	Rotary center, right	1521820	1
3	Fotstegsplatta	Footboard plate	1510669	
2	Fotstegshållare	Footboard holder	1510675	
1	Axel		1510679	
ITEM NO.	Benämning	Title	Part no	YAP.Rev

Note! The images are for reference only. Components marked with \* contact spare part branch.